

Index

0.- General comments

1. -Nomenclature of the parts of a hob

- 1.1- Normal and axial pitches
- 1.2- Normal and axial pressure angles
- 1.3- Helix angle
- 1.4- Gashes
- 1.5- Number of gashes
- 1.6- Cutting face
- 1.7- Tip and side relief
- 1.8- Outside diameter
- 1.9- Total length of hob
- 1.10- Centring bore
- 1.11- Collars and side faces
- 1.12- Tooth profile

2.- Profile calculation

- 2.1- Normal profile
- 2.2- The interference problem
- 2.3- Hobs with lowered pressure angles
- 2.4- Calculation of the semi-topping profile
- 2.5- Verifying the value of semi-topping
- 2.6- Protuberance and full radius

3.- Multi-start hobs

4.- Multi-gash hobs

5.- Hob accuracy tolerances

6.- Materials used to manufacture hobs

- 6.1- High speed steel
- 6.2- Sintered metal carbides

7.- Recoating

- 7.1- The CVD method
- 7.2- The PVD method
- 7.3- The electrodeposition process

8.- Hob wear

9.- Working conditions

- 9.1- Cutting speed
- 9.2- Feed and chip thickness
- 9.4- The Hoffmeister formula
- 9.5- Further considerations on chip thickness
- 9.6- Reducing total hobbing costs
- 9.7- Shifting
- 9.8- Setting up a hob
- 9.9- Considerations on workpiece errors

10.- Cutting time and disposable hobs

11.-Dry cutting and carbide hobs

12.- Hob resharpening

- 12.1- Geometric errors in resharpening
- 12.2- Working condition in resharpening
- 12.3- Ceramic grinding wheels on steel
- 12.4- CBN grinding wheels on high speed steel
- 12.5- Sharpening of carbide hobs
- 12.6- Special pre-coating surface finishing

13.- Big module hobs

14.- Skiving hobs

15.- Special profile hobs

- 15.1- Worm wheel hobs
- 15.2- Hobs for splined shafts
- 15.3- Hexagonal profile hobs
- 15.4- Roller chain sprocket hobs
- 15.5- Fixed-position hobs

16.- Comments on hob manufacturing

17.- Inserted blade hobs

18.- Anomalies in the use of hobs and solutions

- Problems with the hob
- Problems with the gear

19.- Key to the most common abbreviations (acronyms)

20.- Appendix – Table of standard profiles DIN 3972